

Vent-A-Hood®

BBQ Kit Installation Details

NOTE: The BBQ kit is for use with the following standard range hood models.
DAH18, NPH18, NPXH18, PRH18, PRXH18, PWVH18, XRH18, and XRXH18

- 1) Read all instructions thoroughly before beginning installation. Note: These instructions apply to the BBQ kit and standard 18" tall wall mount hoods only.
- 2) When installing a wall mount range hood, it is recommended that the bottom edge of the hood be located no more than 30" above the cooking surface. Exceeding recommended mounting height may compromise performance.
- 3) Remove the BBQ kit from its packaging.

Lift the extension housing assembly to the location on the wall where it will be installed.

Lightly mark the wall with a short, horizontal mark along the top edge of the extension housing. When finished, remove the extension housing from the wall.

- 4) Measure 1/8" below the horizontal mark made in step 3 and lightly mark the wall with a level, horizontal line. Measure where the center (left to right) of the hood will be and mark the lower horizontal line on the wall with a short, vertical centerline.
- 5) Remove the screws inside the top of the back of the extension housing that retain the wood strip that is recessed in the mounting channel. Remove the wood mounting strip from the back of the housing and place the top edge of the strip on the lower, level, horizontal line on the wall. Referencing the vertical centerline from Step 4, place the mounting strip on the wall so it is centered (left to right) in the space where the hood will be located. Drill pilot holes in the strip to prevent splitting. Using proper hardware, attach the mounting strip to at least two wall studs or other support structure.
- 6) Hang the BBQ housing on the mounting strip by aligning the channel at the top of the back of the housing over the wood mounting strip on the wall. While holding the housing in place, mark locations on the mounting strip through the mounting holes in the channel at the top of the housing. Remove the housing and drill 3/32" pilot holes at the center of the marks in the wood strip to prevent splitting.
- 7) Lift the BBQ housing up to the wall and hang the housing on the mounting strip. Secure the BBQ housing to the mounting strip by installing the screws (removed from the strip in Step 5) into the pilot holes drilled in Step 6.
- 8) Remove and discard the wood mounting strip that is located on the back of the range hood.

